

zu beziehen bei

sold by

www.conatex.com



GB Instructions of use for hygrometers.

The hygrometer (moisture meter) measures the relative air humidity at the place of the suspension. Whilst the air pressure (barometer) is the same inside and outside of the house it is not so concerning the air humidity. An agreeable atmosphere in living-rooms is guaranteed in presence of a relative air humidity of 40-70%.

When the function of the device once weakens it may be readjusted. Referring to this you put the device on its rearside upon a cloth being well moistened during about 30 minutes. After that period the instrument should indicate a 95% air humidity. When the indication deviates by more than 5% upwards or downwards the hand will be adjusted to this value by turning the adjustment slot at the rearside. After this adjustment the device will normally function again.